





LED Remote Controller

Model: BR01-11 / BR01-20 / BR01-30 / BR01-40



Operation

1. Pair the remote to receiver

The remote controller needs to be paired to receiver to work. User can pair up to 5 remote controllers to one receiver and each single remote controller can be paired to any receiver.

To pair a new remote to the receiver, please operate with following two steps:

- 1). Cut off the power of receiver and power on again after more than 5 seconds.
- 2). Hold press the two keys noted with pair function simultaneously and briefly within 10 seconds after receiver powered on.

After this operation, the remote is paired to the receiver and ready to work.

2. Unpair the remote controller

To unpair the remote from the receiver, please operate with following two steps:

- 1). Cut off the power of receiver and power on again after more than 5 seconds.
- 2). Hold press the two keys noted with unpair function simultaneously within 10 seconds after receiver powered on.

After this operation, the remote will be unpaired from receiver.

3. Model matching

Each model remote controller is designed to work with matched receivers only. The remote will work improperly if been paired to mismatched receivers.

Each model needs to be matched with different function receivers as below:





- BR01-11 ----- Single color.
- BR01-20 ----- Tunable white (CCT).
- BR01-30 ----- RGB color.
- BR01-40 ----- RGB+White or RGB+CCT.

Specification

Working voltage	DC 3V, CR2032 battery
Wireless protocol	Umi protocol based on SIG BLE Mesh
Frequency band	2.4GHz ISM band
Wireless power	< 7dBm
Working temperature	-20-55°C(-4-131°F)

LED遥控器

型号: BR01-11 / BR01-20 / BR01-30 / BR01-40



操作方法

1. 配对到灯具或控制器

遥控器需要与灯具或控制器配对才能工作。一个灯具或控制器最多可以配对 5 个遥控器, 遥控器则可以与任意灯具或控制器配对。

请按以下步骤操作来完成遥控器配对:

- 1). 将目标灯具或控制器断电, 在超过5秒后再通电。
- 2). 在控制器通电后的10秒内, 同时按下左图中指示的两个配对按键完成配对。

2. 取消配对

请按以下步骤来完成遥控器取消配对操作:

- 1). 将目标灯具或控制器断电, 在超过5秒后再通电。
- 2). 在控制器通电后的10秒内, 同时按下左图中指示的两个取消配对按键来取消当前遥控器的配对。

3. 型号匹配

左图列出的各型号遥控器针对单色、CCT、RGB和多通道设计, 遥控器必须匹配到相应功能的灯具或控制器才能正常工作。

各型号对应的灯具或控制器功能如下:

- BR01-11 ----- 单色
- BR01-20 ----- 冷暖白
- BR01-30 ----- RGB
- BR01-40 ----- RGBW或RGB+CCT

规格

工作电压	DC 3V, CR2032纽扣电池
无线协议	Umi协议, 基于 SIG BLE Mesh
频段	2.4GHz ISM band
无线功率	< 7dBm
工作温度	-20-55°C(-4-131°F)